#### **Seeding Materials for Weather Modification**



# **Goals for Applying Seeding Materials**

- To produce large droplets (<u>hygroscopic seeding</u>) or ice crystals (<u>glaciogenic seeding</u>) in clouds.
- Need to have proper material and equipment.

## Considerations

- 1. Program Objectives
- 2. Overall Cost
- 3. Production of Particles
- 4. Delivery of Material



## **Generator Types**

- Liquid
  - Uses acetone for hot flame.
  - Needs a carrier to put AgI into solution.
- Pyrotechnic
  - AgIO3, Al, Mg, binder.
  - Burn-in-place or ejectable.





#### **Hygroscopic Materials for Seeding**

• What does hygroscopic mean?



## Hygroscopic Nuclei Chemistry

- Objective is to broaden the cloud droplet size distribution in order to promote the collision-coalescence mechanism.
- Commonly used materials (various mixtures):
  - •NaCl most common.
  - NH<sub>4</sub>OH (Ammonium Hydroxide)

•Urea (Also Called Carbamide) -> H<sub>2</sub>N > NH<sub>2</sub>

### **Hygroscopic Seeding Requirements**

- Must create many hygroscopic particles.
- Particles must be dispersed within the cloud volume.



## **Pyrotechnics: Hygroscopic Flares**

- Flares burn hot (>2000 °C).
- Solids are vaporized.
- Vapors quickly cool and form very small solid compounds in extremely large numbers.
- These particles coagulate (stick together) to form larger seeding particles.
- CCN concentrations ~20,000 cm<sup>-3</sup>.

#### **Initial Losses of Nuclei**


Initial Rate of Decrease Due to Brownian Coagulation in Concentration of a Monodisperse Aerosol as a Function of Particle Diameter d and Concentration N<sup>a</sup>

		N (m <sup>-3</sup> ) 10 <sup>13.5</sup>	1014	1014.5
	10	1%	3%	10%
	1.0	1	3	10
d (µm)	0.1	2	7	20
	0.01	3	9	30

<sup>a</sup> Percent decrease per second.

### **Glaciogenic Seeding Requirements**

- Must generate Agl particles (small).
- Particles must nucleate ••• ice crystals.
- Material/Crystals must be dispersed through cloud volume.



#### **Generation of Ice Nuclei Requirements**

- Want to get maximum number of effective ice nuclei per mass of AgI.
  - Cost efficiency.
  - Operations efficiency (i.e., weight, time of operations, etc.).




## **Cloud Seeding Generators**

- May create either liquid or solid particles.
- Normally used to create glaciogenic particles, but can work for certain hygroscopic particles.
- Works by vaporizing the seeding material.
- Requires temperatures greater Than 1000 °C.



Cloud Seeding Generator outside of Clifford Hall in March of 2022.

#### **Electron Microscope Images from Generator**



#### **Particle Yields of Agl Flares**

- Particles created by cooling of vapor.
- Need good airflow.
- Particles coagulate.
- Maximum yield about 10<sup>15</sup> particles per m<sup>3</sup>.
- Approximately 10<sup>14</sup> Ice Nuclei per gram AgI.

## **Agl Cloud Seeding Efficiency**


- <u>Definition</u>: Number of particles per gram of AgI producing ice crystals at a given Temperature.
- May vary as a function of Temperature.
- Difficult to test.




### **Sliver Iodide Efficiency (Activity)**

 Ice Nucleation efficiency of silver iodide at -20 °C on a particle count basis.

Figure 4 from Langer, et al., 1967, J. Appl. Meteor., 6, 963-965



#### **Yields and Efficiency for Cloud Seeding**



Approximately 10<sup>14</sup> Ice Nuclei per gram AgI.

#### **Particle Activity**


- Activation: Formation of an ice crystal on a nucleus.
- Modes of Activation: Deposition, condensation freezing, contact, and bulk freezing.
  - Ideally, would produce many crystals at warm temps (-5° C), none at cold.

## **Types of Particle Activation**

- Deposition Requires larger nuclei and is effective only at colder temperatures.
- Condensation Freezing Relatively effective.
- Contact Requires high concentrations to act very quickly.
- Bulk Freezing Nucleus may dissolve.

#### **Activation Rate**

- Speed of ice nucleation is critical.
- Rate is a function of formulation, temperature, liquid water content.
- The condensation/freezing activate type is fastest.



#### **Activation Rate**




Figure 33. Activation times for  $AgI_{0.8}Cl_{0.2}$ -4NaCl and  $AgI_{0.8}Cl_{0.2}$ -NaCl, the latter being used in the NDCMP (DeMott 1997).

## **Deactivation (Lose of Activation Ability)**


- By UV rays: loss of nucleation ability, up to 90% in one hours.
- By solution.



#### **Photodeactivation of Agl**

- When exposed to UV radiation, the iodine is dissociated from the silver and will go off as a gas.
- The silver remains on the outside of the particle, leaving a coating of silver.
- Pure silver is not an effective ice nuclei.

#### **Photodeactivation of Agl**



Release of iodine from the silver iodide leaves silver behind as a coating on the AgI crystal.


### **Summary of Key Attributes**


- Particle Efficiency
  - Number of active ice nuclei per gram of seeding agent.
- Particle Activity
  - Number of active IN as a function of temperature.
- Activation Rate
  - Speed of activation.

## **Other Materials**


- Pseudomonas syringae (solid baterial) is a rod-shaped, Gramnegative bacterium with polar flagella. (Wikipedia, 2015).
- Naturally occurring.
- Causes water to freeze on plants.

Images of the E. Coli C41 fabricated organic ice nuclei (OIN).





Tp - 120 min



### **Pseudomonas Syringae**

• These proteins serve as effective nuclei to initiate the formation of ice crystals at relatively high temperatures, so that the droplets will turn into ice before falling to the





## Liquid Propane

- Release of liquid propane as a gas from a LP dispenser chills the air to as cold as -100 °C.
- Because of the tremendous local chilling, LP release can generate ice crystals at temperatures as warm as -0.5 °C.
- Rate is ~ 4 oz/min.

